

FILTAPAC ECONOFLO

RECHARGEABLE WATER FILTER

FITTING INSTRUCTIONS

FOR SEMI RIGID PIPES USING PUSH FIT CONNECTORS

1. Cut pipe to correct size to accommodate filter and attach the push fit connectors supplied, being sure to push the pipe fully into the connector. Please note: If replacing an existing filter, do not use the old connectors as they will not be suitable for your new Econoflo.
2. Push the connectors fully onto the filter stub at each end, making sure the water flow is in the right direction.
3. Check that the screw cap is closed but not over tightened.
4. Flush the filter through for 30 seconds to clear carbon dust from the cartridge (the water will run darkly for a few seconds) and check for leaks.

FOR FLEXIBLE HOSE USING JUBILEE CLIPS

1. Cut pipe to correct size to accommodate filter.
2. Push the two short sleeves supplied over the tube connectors at each end of the filter. Push them firmly down against a hard surface until the sleeve is flush with the end of the connector.
3. Fit jubilee clips over the hose, push the hose over the sleeved connector and tighten clips in position on the sleeves.
4. Continue as step 4 above.

Recharge packs available from FILTAPAC 8 Tudor Close Stone ST15 OJY