

THIS PACK WILL ALLOW YOU TO RE-USE YOUR CRYSTAL FILTER. JUST FOLLOW THE INSTRUCTIONS FOR A SIMPLE, COST SAVING ALTERNATIVE. THE RESULT IS BETTER TOO! YOUR RECHARGED FILTER WILL NOT ALLOW CARBON GRANULES TO ESCAPE AND CAUSE BLOCKAGES OR FAILURES IN YOUR WATER SYSTEM.

INSTRUCTIONS FOR RECHARGING THE CRYSTAL 1 & 2 FILTER

1. Turn clear end cap ½" then prise apart as shown in fig.1.
2. Empty out & throw away everything except the two mesh discs and the black/blue sponge which are to be re-used. The foam washer on the nozzle can be left in place but the black "O" ring on the cap should be thrown away.
3. After washing & sterilising the saved parts, reassemble as shown above using new parts from the pack. DO NOT open the bag of carbon. Simply push it firmly into place.
4. Push the end cap into the refilled body and turn until it clicks into place. Then roll the new "O" ring down the body into its groove on the clear cap.
5. Lubricate the "O" ring & threads with silicon or vegetable oil and screw in until you feel the thread hit the stop. DO NOT tighten beyond this or you may damage the housing.
6. Flush through with cold water for about 30 seconds (the water will run darkly coloured for a few seconds then clear)




Fig 1

To ensure clean tasting water, your filter should be recharged or replaced at the start of each season and again after each 30 days of caravanning.

Contents: 1x Bag of silverised activated carbon
 1x 51mm Filter disc 1x 55mm Filter disc
 1x Instruction sheet 1x Black nitrile "O" ring

If your black/blue sponge and/or end washer are deteriorating, make sure that you order a Filtapac spares kit with your next order